

## **WORKING INSTRUCTIONS**

## Imagination • Inspiration • Innovation



1. Position the skip in the desired discharge location.



2. Lower Spreader Beam until the chains go totally slack



3. Wait for 10 seconds to prime the mechanism.



4. Push the remote BUTTON once. The lights on the end of the skip will now illuminate.



5. Raise skip with crane directly off discharge zone, the skip doors will now open & remain open.



6. When clear of spoil, push the remote BUTTON once again – the skip doors will now close automatically, the lights on the end of the skip will now turn off.



7. The skip is now ready to be refilled.







