



REMOTE HANDSET OPERATING INSTRUCTIONS

Activation Button

Push this button to
operate discharge of skip.



DIRECTIONS FOR USE:

1. Position skip in desired discharge location.
2. Lower Spreader Beam until the chains go totally slack
3. Wait for 5 seconds to prime mechanism.
4. Push the remote **BUTTON**. The lights on the end of the skip now illuminate.
5. Raise skip with crane directly off discharge zone – skip doors will open & remain open.
6. When clear of spoil, push the remote **BUTTON again**– skip doors will now close automatically.
7. Skip is now ready to be refilled.

